

ERFURT - DIGITAL NONWOVEN



PVC-free



Non-flammable



Non-woven adhesive



Wall pasting technique



Breathable



Impact-resistant



Excellent light resistance



Dry strippable



PRO E

Environmentally friendly



Printable with eco-solvent and solvent inks



Printable with latex inks



Printable with UV-curable inks





For fairs etc.

The base surface should be dry, clean, firm, absorbent and smooth.

Mark the width of the length on the wall and plumb.





4. Firmly press down the lengths of wallpaper with foam rubber roller.

2a. Use nonwoven adhesive in a ratio of 1:10 for pasting. Use with a pasting machine – no soaking time required or





5. Immediately after adhesion of each strip, carefully dab with a soft, slightly damp, clean cloth to remove any leaking adhesive.

2b. Use the wall adhesion technique – no soaking time required.





6. Cut off excess wallpaper in the corners with a wallpape ring palette knife and a Stanley knife or using scissors.

3a. Where the edges of the print are cut cleanly, butt the edges together, or



7. Slight traces of adhesive on the surface can be removed with a soft, slight ly damp cloth once the wallpaper has dried.

3b. with overlapping lengths of wallpaper, cut the white margins up to the image when dry. Then align the lengths on the wall where they overlap. Make a cut through both layers for a clean join.





8. When you come to redeco rate, the wallpaper can be dry stripped leaving no traces.



Product Description

Manufacturer

A cooperation with:Erfurt & Sohn KG · Wuppertal · www.erfurt.com

Product designation **ERFURT Wallpaper CA**

Raw materials / Manufacture

ERFURT-Digital nonwoven is a hard-wearing, PVC-free wall covering with a pre-coated finished suitable for digital ink jet printing, manufactured from special cellulose and textile fibres, combined with polymer binding agents.

Product data

Dimensions and order no. of textured finishes:

40 x 0,75 m DV 615, DV 617, DV 635, DV 638

Dimensions and order no. of smooth finishes:

40 x 0.75 m DV 662 DV 662 50 x 1,50 m

Weight: ca. 220 g/m2 w

Product characteristics

Smooth or textured, hot roll-pressed surface

w Its water vapour permeability conforms to DIN 52615.

corresponding to a diffusion-equivalent air layer thickness

of 0,05 m

Fire protection class according to DIN EN 13501-1, corresponds w

to C, s1, d 0

PVC-, softener- and solvent-free, fibreglass-free w w No addition of heavy metal compounds or formaldehyde

Dimensionally stable and covers over cracks (Class A) Excellent base surface coverage due to the pigmentation

in the wallpaper

Dry strippable without leaving any traces w

Printing properties

w

Up to 30% less ink used w

Suitable for eco-solvent, solvent, latex and UV inks w

Suitable for eco-friendly digital printing w

Color Alliance certified w

ERFURT-Digital nonwoven wallpapers can be used on all interior base surfaces that can be wallpapered over. The base surface should be carefully prepared and must be dry, clean, firm, slightly absorbent and smooth.

Remove all wallpaper and coats of paint that are no longer adhering to the wall. Smooth out rough base surfaces with plaster-based filler.

Prime very absorbent base surfaces with solvent-free primer. Please read BFS data sheets nos. 7 and 16.

Hang using the wall adhesion technique

Use nonwoven adhesives, such as Metylan secure/Metylan NP New Plaster Paste, at a ratio of 1:10 = 1 kg in 10 l of water or similar. Apply the adhesive evenly to the base surface and lay the cut lengths of wallpaper dry into the bed of adhesive. Please read the adhesive manufacturer's instructions for use.

Using a pasting machine

Paste ERFURT-Digital nonwoven using a pasting machine, fold it and hang it immediately without allowing for a soaking time. Use nonwoven adhesives, such as Metylan secura/Metylan NP New Plaster Paste, at a ratio of 1:10 = 1 kg in 10 l of water or similar. Please read the adhesive manufacturer's instructions for use.

Adhesion

Hang ERFURT-Digital nonwoven perpendicular, with the lengths butt jointed to each other. Smooth out the bubbles with a foam roller or a wallpapering palette knife. Press excess lengths at ceilings, skirtings, windows etc. into the corners with a plastic trowel and cut off with a Stanley knife. Ensure the wall covering does not overlap. Immediately remove any traces of adhesive from the surface.

Butt seam adhesion

For prints with clean cut edges, the edge of one strip is butted up against the edge of the adjoining strip.

Double-cutting adhesion

For overlapping printed wallpaper strips, cut off the white edges up to the pattern when the wallpaper is dry. Then align the strips on the wall in the area where they overlap and press down with a rubber roller or wallpaper spatula to remove any air bubbles. For a clean seam, cut through the two layers of overlapping wallpaper in one cut, remove the wallpaper and adhesive residues and finish off with a seam roller. Press excess wallpaper on ceilings, skirting boards, windows etc into the corners with a plastic trowel and trim with a Stanley knife. Ensure the wall covering does not overlap. Immediately remove any traces of adhesive on the surface with a soft, slightly damp cloth.

ERFURT WB Wallpaper CA wall coverings are extremely hard-wearing. For heavily used environments such as catering establishments, swimming pools or event venues, we recommend coating the wallpaper after hanging with a high-quality clear varnish (e.g. Capaplex by Caparol) to protect the print.

Dry strippable

ERFURT-Digital nonwoven can be dry stripped without leaving any traces when you come to redecorate.